材质：128g双铜纸正反面，彩印，风琴折页

产品尺寸：150mmX76mm

展开尺寸：150mmX760mm

注意折叠方式：封面朝上

请打样实物确认后才能批量印，如有问题，第一时间联系我司，否则退货重印，谢谢！！

HAÚSTIER

WF08
SENSÖRLÜ SU SEBİLİ
Kullanım Kılavuzu



Güvenlik Önlemleri

Uyarı

- Tüm ambalaj malzemelerini uygun şekilde atın. Bazı parçalar plastik torbalara sarılmış olabilir; bu torbalar boğulmaya neden olabileceği için çocuklardan ve evcil hayvanlardan uzak tutun.
- Evcil hayvanın pranzını kullanım amacı dışında hiçbir şey için KULLANMAYIN.
- Yalnızca üretici tarafından önerilen veya satılan aksesuarları kullanın. Üretici tarafından önerilmeyen veya satılmayan aparatların kullanılması güvenlik bir duruma neden olabilir. Evcil hayvan pınarında değişiklik YAPMAYIN.
- Cihaz arızalıysa veya hasar görmüşse çalıştırmayın. Cihazı kendiniz tamir etmeye ÇALIŞMAYIN. Daha fazla talimat için derhal müşteri hizmetlerimizle iletişime geçin.
- Cihaz uzun süre kullanılmayacaksa, pilin durumunu korumak için lütfen pil paketini her 4 ayda bir şarj edin.
- Cihazın bakımını ve temizliğini yapmadan önce lütfen güç kaynağı bağlantısını kesin ve cihazın soğumasını bekleyin.
- Bu ürün yalnızca iç mekan kullanımı içindir.
- Bu ürünün susuz çalıştırılmasına izin verilmez.
- Kurulumdan sonra cihazı kontrol edin. Bağlantı noktalarında su varsa cihazı AÇMAYIN.
- Takılıp düşmeleri önlemek için, güç kablosunu daima yürüme alanlarının uzağına yerleştirin.
- Filtreyi her 2-4 haftada bir veya ateş hızı belirgin şekilde düştüğünde değiştirin. Birden fazla evcil hayvarınız varsa, filtrelerin tıkanma durumuna göre daha düzenli değiştirmeniz gerekebilir.

Dikkat

- Cihazı yalnızca DC çıkışı 5V 2A güç adaptörü ile kullanın için uygundur. Lütfen ilgili ulusal ve bölgesel standartları karşılayan bir güç adaptörü kullanın; aksi takdirde ürünle zarar verebilir veya güvenlik tehlikelerine yol açabilirsiniz (güç adaptörü dahil değildir).
- Evcil hayvan su pınarını hava koşullarına veya 0°C / 40°F altındaki sıcaklıklara maruz kalacağı yerlerde KURMAYIN veya SAKLAMA-YIN.
- Uzun süre evden ayrılmadan önce su sebilindeki kalsi su miktarını ve pil durumunu daima kontrol edin.
- Evcil hayvarı su pınarı üzerinde ve ambalajında listelenen tüm önemli uyarıları okuyun ve bunlara uyun.

İçindekiler

Ambalajı açın ve aşağıdaki bileşenlerin eksiksiz olup olmadığını kontrol edin.




1 x Batarya | 1 x Paslanmaz Çelik Su Tepsisi | 1 x Filtre (Standart Kit)



1 x Pompalı Filtre Tepsisi | 1 x Paslanmaz Çelik Su Haznesi | 1 x USB-C Kablosu

Ürüne Genel Bakış

Önden Görünüm



1. Su Çıkışı (Ağızlık)
2. Hareket Sensörü
3. Çıkarılabilir Pil Paketi
4. Paslanmaz Çelik Su Tepsisi
5. Filtre
6. Filtre Tepsisi
7. Güç Kablosu Su Pompası
8. Paslanmaz Çelik Su Haznesi

Not: 6 ve 7 numaralı bileşenler önceden birleştirilmiştir ancak bakım amacıyla birbirlerinden ayrılabilirler.

Çalışma Modu Tanıtımı

Pil güçlüyle çalışma: Kablosuz olarak kullanılabilen yerleşik bir şarj edilebilir pil bulunur. Priz bulunmayan kapalı alanlar için uygundur.

Not: İlk kez kullanıldığında, cihazın önce tamamen şarj edilmesi gerekir. Hemen kullanmanız gerekiyorsa, harici güç kablosunu bağlayabilir; su pınarını çalıştırken şarj edebilir ve tamamen şarj olduğunda kabloyu çekebilirsiniz.

1. Zamanlayıcı Modu: Su her 15 dakikada bir salınır.


2. Hareketle Etkinleşen Mod:

- Su pınarının yerleşik bir sensörü vardır; algılama aralığında bir evcil hayvan aktivitesi algılandığında otomatik olarak 20 saniye boyunca su verir.
- Algılama aralığı: Algılama açısı 120°, algılama mesafesi 1.5 metredir.



3) Hareketle etkinleşen su çıkış modu açıldıktan sonra, 1 saat boyunca hiçbir hareket algılanmazsa cihaz, suyu filtrelemek ve temiz tutmak için otomatik olarak 20 saniye boyunca su akışı sağlar.

Not: Su pınarının arkası evcil hayvanları algılayamaz, bu nedenle evcil hayvanlarını su içmesini engellememek için ürünün arkasını duvara yaslayarak kullanmanız gerekir.



Göstergeler ve Düğmelere Genel Bakış



Işık Bölümü

Pil Göstergesi

1) Yanıp sönen mavi: Harici güç kaynağından şarj ediliyor.
2) Sabit yanan mavi: Pil tamamen şarj oldu.
3) Yanıp sönen kırmızı: Pil düşük, şarj edilmesi gerekiyor.
4) Kapalı durum: Pil güçü yeterli. Mevcut pil seviyesi düşük güç uyarısının üzerinde.

Cihaz Çalışma Göstergesi

Zamanlayıcı Modu

Bu mod seçildiğinde gösterge ışığı yanar, kısa bir bip sesi duyulur ve mod başlar.
1) Sabit yanan beyaz: Çalışma durumu, 20 saniye boyunca su akışı sağlar.
2) Nefes alan beyaz (Yavaşça yanıp sönen): Su akışları arasındaki 15 dakikalık geri sayım.
3) Kapalı durum: Bu mod seçili değil.

Hareketle Etkinleşen Mod

Bu mod seçildiğinde gösterge ışığı yanar, kısa bir bip sesi duyulur ve mod başlar.
1) Sabit yanan beyaz: Çalışma durumu; hareket sensörü tetiklendi, 20 saniye boyunca su çıkışı sağlar.
2) Nefes alan beyaz (Yavaşça yanıp sönen): Algılama durumu; algılama aralığında hareket arıyor.
3) Kapalı durum: Bu mod seçili değil.

Düğme Bölümü

Güç (Açma/Kapatma) Düğmesi

Cihazı açma: Düğmeyi 2 saniye basılı tutun; sensör simgesi göstergesi yanar, kısa bir bip sesi duyulur, cihaz açılır ve varsayılan olarak hareketle etkinleşen moda geçer.

Mod değiştirme: Düğmeye tekrar bastığınızda cihaz zamanlayıcı moduna geçer.

Kapatma: Düğmeyi 2 saniye basılı tutun; gösterge ışığı söner, uzun bir bip sesi duyulur ve cihazın gücü kapatılır.

Pil Paketi

Su sebilinde yerleşik bir şarj edilebilir pil bulunur; lütfen günlük kullanımda aşağıdaki hususlara dikkat edin:

1. Yerleşik pil söklülemez. Pil performansının düşmesini veya pile zarar gelmesini önlemek için lütfen kendiniz sökmeyin. Ciddi durumlarda aşırı ısınma, yangın veya yaralanma gibi elektriksel güvenlik tehlikeleri oluşabilir.

2. Ürün uzun süre kullanılmadığında, pil ömrünün olumsuz etkilenmesini önlemek için lütfen ürünü en az 4 ayda bir şarj edin.

3. Düşük güç uyarısı verildiğinde, pil ömrünü korumak için lütfen pili mümkün olan en kısa sürede şarj edin.

4. Düşük sıcaklıklarda kullanmaktan kaçının; aksi takdirde pil gücü düşebilir, bu normal bir durumdur.

5. Su pınarını şarj etmek için lütfen 5V 2A bir güç adaptörü kullanın (güç adaptörü dahil değildir).

6. Pil yangın veya doğrudan güneş ışığı dahil olmak üzere hiçbir doğrudan ısı kaynağına maruz BIRAKMAYIN.

7. Cihaz hurdaya ayrılmadan önce pil su pınarından çıkarılmalıdır.

8. Herhangi bir pattama tehlikesini önlemek için su pınarını veya Pil Paketini ateşe, suya ya da diğer sıvılara ATMAYIN.

9. Lityum iyon pil evsel atıklarınızla birlikte ATMAYIN. Yerel çevre yasalarına ve düzenlemelerine uygun olarak bertaraf edin.

10. Pil paketini 60°C'nin (140°F) üzerinde ısıtmayın veya yakmayın. Pil paketini çocuklardan uzak tutun.

Nasıl Kullanılır

Adım 1



Filtreyi temiz bir kapta 5 dakika bekletin, ardından musluk suyuyla iyice durulayın.

Notlar:

1) Pınar açımadan önce filtre tamamen ıslatılmalıdır; aksi takdirde su filtreden rahatça akamaz ve taşmaya neden olabilir.

2) Yüzeydeki olası tozların suya karışmaması için filtreyi su pınarının kendi su haznesinde ıslatmayın.

Pil paketinin suya batırılması kesinlikle yasaktır.

Su çıkış ağzının temizliği için Sadece Durulayın! Pil paketini suya batırmayın ve makineye tekrar takmadan önce tamamen havada kurumasını bekleyin.

Adım 2



Su tepsisini, filtre tepsisini ve su haznesini temiz suyla yıkayın.

Not: Yalnızca paslanmaz çelik su tepsisi ve paslanmaz çelik su haznesi bulaşık makinesinde yıkanabilir.

Diğer bileşenlerin temizlik için bulaşık makinesine konulması kesinlikle yasaktır.

Adım 3



Hazneye su ekleyin.

Not: Su seviyesini daima Min ve Max çizgileri arasında tutun.

Adım 4



Filtre tepsisini takın ve filtreyi filtre tepsisine yerleştirin.

Adım 5



Su tepsisini su haznesine monte edin.

Adım 6



Pil paketini yerine yerleştirin.

Adım 7



Cihazı açmak için güç düğmesini 2 saniye boyunca basılı tutun.

Bakım Talimatları

1) Filtreyi ve süngeri her 2-4 haftada bir değiştirin.

2) Pompayı ve su pınarını her 1-2 haftada bir temizleyin.

3) Pompanın kullanım ömrünü uzatmak için lütfen makineyi çalıştırmadan önce daima su ekleyin.

Adım 1



Pompayı tepsiden ayırın.

Adım 2



Kelepçeyi çevirtin ve pompa gövdesini çıkarın.

Adım 3



Pompa kapağını çıkarın ve süngeri filtreyi dışarı alın.

Adım 4



Fırça kancasını kullanarak pervaneyi çıkarın, ardından parçaları suyla yıkamak için fırçayı kullanın.

Pil Nasıl Şarj Edilir

Adım 1



Pil bölmesini çıkarmak için her iki taraftaki düğmelere basın.

Adım 2



Pil paketinin arkasındaki lastik kapağı açın ve şarj portunu bulun.

Adım 3



Cihazla birlikte gelen USB-C kablosunu bağlayın ve ardından herhangi bir 5V/2A adaptöre (dahil değildir) takın.

Adım 4



Şarj işleminin başlatmak için fişi prize takın.

Sorun Giderme

Sorun	Çözüm
Pompa çalışmayı durdurdu.	1) Hazneye MIN ve MAX çizgileri arasında su doldurun. 2) Pompayı, su haznesini ve içine teknesini temizleyin.
Üst düğmeye basılıyor ancak cihaz açılmıyor	1) Tepsi bileşenlerinin ve pil bölmesinin temas noktalarında su olup olmadığını kontrol edin. Varsa, cihazı açmadan önce bileşenleri silerek kurulayın ve tekrar açmayı deneyin.
Filtreleri ne sıklıkla değiştirmeliyim? Nereden temin edebilirim?	Filtre ve süngerin her 2-4 haftada bir değiştirilmesi önerilir.
Su çıkış hızı yavaşlıyor	Haznedeki su seviyesinin düşük olup olmadığını kontrol edin. Bu durumda su akışının yavaşlaması normaldir; su akışındaki sonra su çıkış hızı normale dönecektir.

Teknik Özellikler

Ürün Modeli	WF08
Ürün Boyutları	200 x 225 x 175 mm
Pil Kapasitesi	4000mAh
Voltaj / Akım	5V 2A
Su Haznesi Kapasitesi	3L
Net Ağırlık	840g
Malzeme	SUS 304 Paslanmaz Çelik + ABS

HAÚSTIER

WF08
SENSOR-CONTROLLED
WATER DISPENSER
User Manual



Safety Precautions

! Warning

- Dispose of all packaging materials properly. Some items may be packed in plastic bags; these bags could cause suffocation; keep away from children and pets.
- Do NOT allow small children to play with, in or around the pet water fountain.
- To reduce the risk of injury, please keep close supervision when the appliance is used near children.
- Do NOT use the water fountain with pets not able to reach the water tray or with any physical disability.
- Do NOT immerse the battery compartment in water at any time as it may damage electronic components.
- Do NOT place any foreign object in the water tank.
- Do NOT disassemble the pet fountain other than components as instructed in this User Manual.
- Do NOT use the pet fountain for anything other than its intended use.
- Only use attachments recommended or sold by the manufacturer. The use of attachments not recommended or sold by the manufacturer may cause an unsafe condition. Do NOT modify the pet fountain.
- Do NOT operate any appliance if the unit is malfunctioning or has been damaged in any manner. Do NOT repair the unit by yourself. Contact our customer service immediately for further instructions.
- If the device is not in use for a long time, please charge the battery pack once every 4 months to maintain the battery in good condition.
- Please disconnect the power supply and detach the battery compartment before maintaining and cleaning the machine.
- This product is for indoor use only.
- This product is not allowed to run without water.
- Check the device after installation. Do NOT turn on if there is water on the contact points.
- To avoid tripping, always position the power cord out of the way of foot traffic.
- Change the filter every 2-4 weeks or when the flow rate has noticeably reduced. For two or more cats, you may need to replace the filters more regularly if it becomes blocked.

Caution

- The product is only applicable to DC output 5V 2A power adapter. Please use a power adapter that meets the relevant national and regional standards, otherwise it will damage the product or cause potential safety hazards (power adapter not included).
- Do NOT install or store the pet water fountain where it will be exposed to weather or temperatures below 0°C / 40°F.
- Check the remaining water volume and battery status in the water fountain before leaving for extended time.
- Read and observe all important notices listed on the pet water fountain and in the packaging.

In the Box

Unpack and check whether the following components are complete.



1 x Battery Pack | 1 x Stainless Steel Water Tray | 1 x Filter *Standard Kit




1 x Filter Tray With Pump | 1 x Stainless Steel Water Tank | 1 x USB-C Cable

Product Overview

Front View

1) Spout
2) Motion Sensor
3) Detachable Battery Pack
4) Stainless Steel Water Tray
5) Filter
6) Filter Tray
7) Water Pump with power cord
8) Stainless Steel Water Tank



Note: Components 6 and 7 are pre-assembled but can be detachable for maintenance purposes.

Working Mode Introduction

Battery powered : there is a built-in rechargeable battery, which can be used without plugging in. It is suitable for indoor areas without power sockets.

Note : when used for the first time, it needs to be fully charged before use. If you need to use it immediately, you can connect the external power cord, charge the water fountain while working, and then unplug it when it is fully charged.


Water outlet mode :

1. Timer Mode : water releases once every 15 minutes.

2. Motion-activated Mode :


1) The water fountain has a built-in sensor, and when the pet activity is detected within the sensing range, it will automatically give water for 20 seconds.

2) Sensing range: induction angle 120°, sensing distance 1.5m.



3) After the motion-activated water outlet mode is turned on, if there is no activity detected within 1 hour, the machine will automatically water out for 20 seconds to filter the water and keep it clean.

Note : The back of the water fountain cannot sense pets, so it is necessary to use the back of the product against the wall to avoid affecting pets drinking water.



Indicators and Buttons Overview



Lighting Part :

Battery Indicator

1) **Flashing blue :** the external power supply is being charged.
2) **Steady blue :** the battery is fully charged.
3) **Flashing red :** the battery is low and needs to be charged.
4) **Off state :** battery power is sufficient. The current battery exceeds the low power warning.

Device Operation Indicator :

Timer Mode

· When this mode is selected, the indicator lights up and is accompanied by a short beep, this mode will start.

1) **Steady white :** working state, water release for 20 seconds.
2) **Breathing white :** countdown of 15 minutes between water releases.
3) **Off state :** this mode is not selected.

Motion-activated Mode

· When this mode is selected, the indicator lights up and is accompanied by a short beep, this mode will start.

1) **Steady white :** working state, motion sensor triggered, water outlet for 20 seconds.
2) **Breathing white :** detecting state, searches for motion within the detection range.
3) **Off state :** this mode is not selected.

Button Part :

Power (Toggle) Button

Power on :

press and hold the button for 2 seconds, the sensor symbol indicator lights up and is accompanied by a short beep, the product is powered on and enters motion-activated mode by default.

Switching modes :

Press the button again, it will switch to timer mode.

Shut down :

Press and hold the button for 2 seconds, the indicator will turn off and be accompanied by a long beep, and the product is powered off.

Battery Pack

The water dispenser has a built-in rechargeable battery, please pay attention to the following items in daily use :

1. The built-in battery cannot be disassembled. Please do not disassemble it by yourself to avoid a decline in battery performance or damage to the battery. In serious cases, electrical safety hazards overheating, fire or injury may occur.

2. If the product has not been used for a long time, please charge the product at least once every 4 months to avoid affecting the service life of the battery.

3. When low power is prompted, please charge the battery as soon as possible to avoid affecting the service life of the battery.

4. Avoid using it at low temperature, otherwise, the battery power will decrease, which is a normal phenomenon.

5. Please use the 5V 2A power adapter(power adapter not included) to charge the water fountain.

6. DO NOT expose the battery to any direct heat source, including fire or direct sunlight.

7. The battery must be removed from the water fountain before it is scrapped.

8. DO NOT dispose of the water fountain or the Battery Pack in fire, water or other liquids. This is to avoid any explosion hazards.

9. DO NOT dispose of the Li-ion battery in your household waste. Dispose of it by following your local environmental laws and regulations.

10. Do not heat above 140 °F [60 °C] or incinerate the battery pack. Keep the battery pack away from children.

How to Use

Step 1



·Soak the filter in a clean bowl for 5 minutes, then rinse the filter thoroughly with tap water.

Notes :

1.) The filter must be fully soaked before the fountain is turned on; otherwise, water may not flow through the filter smoothly and cause spillage.

2.) Do not soak the filter in the water tank of the fountain in case of any surface dust.

! The battery pack is strictly prohibited from being immersed.
* For spout cleaning, Rinse Only! Do not immerse the battery pack in water, and air dry it thoroughly before refitting it to the machine.

Step 2



·Wash the water tray, filter tray and water tank with clean water.

Note : Only the stainless steel water tray and stainless steel water tank are dishwasher safe.

The rest of the components are strictly prohibited to put into the dishwasher for cleaning.

Step 3



·Add water to the tank.

Note : Keep the water level between the Min and Max level.

Step 4



·Install the filter tray and place the filter on the filter tray.

Step 5



·Install the water tray into the water tank.

Step 6



·Install the battery pack in position.

Step 7



·Press and hold for 2 seconds to power on.

Care Instructions

1) **Replace the filter and foam every 2-4 weeks.**

2) **Clean the pump and fountain every 1-2 weeks.**

3) **To extend the life of pump, please add water before starting the machine.**

How to Clean the Pump

Step 1



Detach the pump from the tray.

Step 2



Loosen clamp and remove pump body.

Step 3



Remove the pump cover and take out the foam filter.

Step 4



Remove the impeller by the brush hook, then use the brush to clean the parts with water.

How to Charge the Battery

Step 1

Press the buttons on both sides to remove the battery compartment.

Step 2

Open the rubber cap on the back of the battery pack and find the charging port.

Step 3

Connect it with the USB-C cable (included), and then connect to any of the 5V2A adapters (not included).

Step 4

Plug into the socket for charging.

Troubleshooting

Problem	Solution
The pump stops working.	1) Fill in water between MIN and MAX. 2) Clean the pump, water tank, and drinking basin.
Press on the Top Button, but the device cannot be turned on.	1) Check if there is water on the contact points of the tray components and the battery compartment. 2) If there is, wipe the contact points dry and try to turn it on again.
How often should I change the filters? Where to get them?	It's recommended to replace the filter and sponge every 2-4 weeks.
Water output speed slows down.	Check if the water level in the tank is low, it's normal if the water output speed slows down in this case, after adding water, the water output speed will turn to normal.

Specifications

Product Model	WF08
Product Dimensions	200x225x175 mm / 7.9x8.9x6.9 inch
Battery Capacity	4000mAh
Voltage / Current	5V 2A
Water Tank Capacity	3L / 101oz
Net Weight	840g
Material	SUS 304 Stainless Steel + ABS

FC RoHS CE

Made in China